

Recommendations:

When pouring sockets, always the instructions of the manufacturer of the medium used for socketing (e.g. Wirelock®) shall be followed up. In addition Hendrik Veder recommends, prior to put into use, to proof load test the socketed connection up to a proof load of 40% of the minimum breaking load of the steel wire rope. The steel wire rope may not move more than 2% of the cone length in the socket.

